



SYRINGE - PACKAGED ADHESIVE PASTES

- Diemat adhesive paste products are offered in EFD pneumatic syringes upon request. Sizes include 3 cc, 5 cc, and 10 cc, filled from 10 to 100% of rated volume, as specified by the customer.
- The syringes are shipped in divider boxes, which are placed into Styrofoam coolers containing dry ice. Remove the inner box from the cooler and place into a freezer at -40°C immediately upon receiving. Dry ice should be present inside the cooler at time of delivery. A temperature indicator is also included in each package. The indicator should appear as a solid blue “ice cube”. If the contents of the package had been allowed to increase in temperature during shipment, the cube will show signs of deformation. The amount of deformation is directly proportional to the extent of thawing that had taken place.

Note: Diemat adhesive products are chemically stable. Freezing is required only to prevent the settling of fillers when the product is stored in a syringe. When stored at -40°C, these products will have a shelf life of at least one year.

- Syringes should be stored at -40°C standing upright with syringe tip down.
- Remove individual syringes from the freezer only as needed.
- Thaw syringe at room temperature for one to two hours with the tip down.
- Place syringe into dispenser and begin application of adhesive.
- Use material in a syringe promptly to avoid separation of adhesive components upon standing at room temperature. Under normal conditions, product should remain homogeneous for at least an eight hour period after removed from the freezer.
- Do not refreeze. Dispose of any unused material by accepted methods.
- For more information on this or any Diemat products contact:

Diemat, Inc.
19 Central St.
Byfield, MA 01922 USA
Phone: +1 978-499-0900
Fax: +1 978-499-8484
Email: info@diemat.com
Web: www.diemat.com